Hands-on A3: Packet Tracer Step-by-Step Guide

Follow these steps to set up a simple firewall:

PART 1

- 1. Start Packet Tracer.
- 2. Take few minutes to become familiar with the interface. Your lecturer will explain you important parts of the interface.
- 3. Click on **Switches -> (2950-24)**. Then click on the topology area (centre). A Switch will appear (Switch0).
- 4. Click on **End Devices -> Generic** (PC-PT). Then click on the topology area. A PC will appear (PC0).
- 5. Click on Connections -> Copper Straight-Through.
 - a. Click on PCO. Select FastEthernetO.
 - b. Click on Switch. Select FastEthernet0/1.
 - c. A link will appear between the hub and the PC. This is an Ethernet connection.
- 6. Similarly add another PC (PC1) and connect them to the Switch.
- 7. Click on PCO. You will see a window with 4 panes (Physical, Config, Desktop and Software/Services). You can switch on/off the pc and configure various software/hardware parameters through this window.
- 8. Click on **Desktop -> IP Configuration**
 - a. Select 'Static'
 - b. Enter the IP Address 192.168.1.1
 - c. Enter the sub-net mask 255.255.255.0
 - d. Close the window
- 9. Similarly, set the IP addresses 192.168.1.2 to PC1.
- 10. Click on PC0
 - a. Go to **Desktop -> Command Prompt**
 - b. Type ipconfig end enter.
 - c. You will see the IP configuration of the computer.
 - d. Type **ping 192.168.1.2** and enter
 - e. You will see echo replies from 192.168.1.2 (PC1).
 - f. You have just tested the network connection between PC1 and PC2.
- 11. Similarly, tests the network connectivity from PC1 to PC1.
- 12. You have just implemented a simple network with 2 PCs.

PART 2

- 1. Click on Routers. Select Router (1941). Add it to the topology.
- 2. Click on End Devices again -> Generic (Server-PT). Add it to the topology. (Set IP: 192.168.2.1)
- Connect GigabitEthernet0/0 and GigabitEthernet0/1 interfaces of the Router0 to Switch0
 and Server0 respectively. (Note: use Connections -> Copper Cross-Over for connecting
 Router to Server).
- 4. Click on Router1 Go to Config
 - a. Click on **GigabitEthernet0/0**. Set the IP address to 192.168.1.254 and the subnet mast to 255.255.255.0 then Select 'On.' This will bring up the router interface.
 - b. Click on **GigabitEthernet0/1**. Set the IP address to 192.168.2.254 and the subnet mast to 255.255.255.0 then Select **'On'**
 - c. You have just configured a router connected to two networks with the minimum required configuration.

PART5

- 1. Go to the command prompt of PCO.
 - a. Can you ping to 192.168.1.254 (interface GigabitEthernet0/0 of the router)?
 - b. Can you ping to 192.168.2.1? If you cannot ping, what is the reason?

 - c. Correct the above issue.
 - d. Now check the connectivity of all networks (ping from PCs to Server and Vice versa)

PART6 – Setting Up **firewall** through Router0.

 Go to CLI of Router1 and enter the following commands: (Press ctrl+z. You will see either Router# or Router> prompt.)

Router>enable

Router#config t

Router(config)# access-list 101 permit tcp any any

Router(config)#interface gig0/0

Router(config-if)#ip access-group 101 in

Router(config-if)#^Z

Router#

2. **The same as 1**, give access permit so that only PC1 can ping the Server (send packet) using commands below:

Go to **Config mode** and enter:

access-list 1 permit 192.168.1.1 0.0.0.0 <- This is wildcard mask 0 is exact match - 1 is don't care Go to **interface gig0/0** and enter:

ip access-group 1 in

3. You can see all access list by entering this command:

Router#show access-list

- 4. Test whether you can ping the ServerO from PCO and PC1?
- 5. **Well done**, you have just implemented a simple Firewall.